


City of Lynchburg


Lynchburg Regional Airport

100LL Self Service Fuel Pump

1. Insert credit card with the stripe up and to the left.




2. Select "New" using the buttons on the side of the screen. If you have fueled recently select your aircraft from the list.




3. Using the buttons on the left and right side of the screen select the tail number for your aircraft.




4. Once the tail number is correct press the button to the left of "Accept".




5. Next select if you wish to purchase by dollar amount or gallons of fuel using the buttons to the left of the screen.



6. Enter the quantity or dollar amount for your transaction.



7. Once the amount is selected press the "Enter" key on the keypad below the screen.



8. The pump will now be enabled.

9. Follow manufactures safe fueling standards for your aircraft and placarded safety messages.




10. Turn pump to the "On" position and dispense fuel.



11. When completed with the transaction turn the pump to the "Off" position.



12. When you move the pump to the "Off" position the transaction will end and you will be prompted for a receipt. Select your answer with the keys to the left of the screen.



13. Be sure to retract the hose wheel before departing.